

UNPLANNED UTILITY EXCAVATION REPAIR / REPLACEMENT

1. PREPARATION

- a. Make sure service trucks have and are ready for deployment of wattles, gravel bags, dewatering bag, or other materials for inlet protection and sediment control.

2. PROCESS

- a. Slow the discharge.
- b. Inspect flow path of discharged water.
- c. Protect water inlet areas by placing inlet protection devices around or up stream of inlet.
- d. Follow planned repair procedures.
- e. Haul off spoils of excavation.
- f. Use dewatering bags or pumps and check hourly for effectiveness.

3. ACTIONS

- a. Repair eroded areas as needed.
- b. Follow planned repair procedures.
- c. Remove any inlet protection and dewatering bags and discard appropriately.
- d. Clean up the travel path of trucked excavated material.

4. DOCUMENTATION

- a. Complete paperwork.